Instruction Manual Book

VIPER JET

87.79in ARF COMPOSITE

95% PRE BUILT ARF ALMOST READY TO FLY



SPECIFICATION

- Wingspan: 2230mm (87.79 in).
- Length: 2173 mm (85.55 in).
- Flying weight: 14-14.5 Kg
- Gear type: Electric Retract and Brakes are included with controller box (included).
- Servo: 2 aileron; 2 flap; 2 elevator; 1 rudder; 1 Nose steering; 3 Gear door.
- Engine: Turbine Jet Engine with 140-160N (not included)
- Gravity CG: 195mm (7.67 in) Back from the leading edge of the wing, at the fuselage
- Control throw Ailerons: Low: 12mm up/down
- Control throw Elevators: Low: 10mm up/down
- Control throw Rudder: Low: 35mm right/left
- Control throw Flaps: Mid: 25mm down; Landing: 40mm down
- Plane type: Jet Scale

UNDER SAFETY PRECAUTIONS

This radio control model is not a toy!

- **It is highly recommended that first-time builders seek advice of experienced modelers before beginning assembly.**
- **Assemble this kit only in places out of children's reach!**
- **Take enough safety precautions prior to operating this model. You are responsible for this model's assembly and safe operation!**
- **Always keep this instruction manual ready at hand for quick reference, even after completing the assembly.**

Made in Vietnam

www.modellmarkt24.ch

TABLE OF CONTENTS

- Introduction....2
- Warranty....3
- Disclaimer....3
- Safety precaution....3
- Important building notes....3
- Suggestion....3
- Flight warnings....4
- Covering tools....4
- Adhesives and required tools....4
- Academy of model aeronautics national....4
- Academy of model aeronautics national model aircraft safety code....4
- Parts listing (not included)....6
- Tools & supplies needed....6
- Symbols used throughout this instruction manual comprise....6
- Installing the ailerons and flaps servos....9
- Installing the light wing and....11
- Installing the main landing gear and gear door.11
- Installing the main gear door servos....14
- Joining the fuselage....16
- Secure the wing to the fuselage....17
- Installing the vertical and stabilizer pushrod....19
- Installing the elevator servos....20
- Installing the elevator pushrod....21
- Installing the horizontal stabilizer to fuselage....22
- Installing the nose gear retract....23
- Nose door installing....24
- Installing the exhaust pipe....26
- Installing the fuel tank....27
- Fuel system....28
- Installing the smoke pump....29
- Smoke system....29
- Installing the engine....30
- Installing the receiver, battery, controller box and switch....32
- Installing the cockpit fuselage....32
- Balancing....33
- Lateral balance....33
- Control throws....35
- Flight Preparation Pre-flight check....36
- For your radio installation basic connection for
- Airplane and adjustment of servos....36
- Nose gear dimensional detail....37
- Main gear dimensional detail....37
- I/c flight guidelines....38

INTRODUCTION

Thank you for purchasing BlackHorse Model products.With over 19 years experience inproduction and fly testing, BlackHorse Model is committed to bring the best quality products and good service to customers. Along with a team of creative engineers and skilled workers, we will always accompany with customers by our great experiences, fully enthusiasm...which will burn our passion!! Joining with us to explore and conquer challenges inthesky...

Your satisfaction is our success.Please read through this manual before starting construction.

Academy of Model Aeronautics: If you are not already a member of the AMA, please join! The AMA is the governing body of model aviation and membership provides liability insurance coverage, protects modelers' rights and interests and is required to fly at most R/C sites.

Academy of ModelAeronautics
5151 East Memorial Drive Muncie IN 47302-9252

Tele. (800) 435-9262
Fax. (765) 741-0057

Or via the Internet at: http://www.modelaircraft.org

AMA SINCE 1939

www.modellmarkt24.ch

WARRANTY

Black Horse Model guarantees the component parts in this kit to be free from defects in both material and workmanship at the date of purchase by the purchaser.

This warranty does not cover cosmetic damage or damage due to acts of God, accident, misuse, abuse, negligence, commercial use, or modification of or to any part of the Product.

This warranty does not cover damage due to improper installation, operation, maintenance, or attempted repair by anyone other than Black Horse Model.

Further, Black Horse Model reserves the right to change or modify this warranty without notice.

DISCLAIMER

Read this disclaimer carefully before using this product. Please strictly follow the instruction manual to assemble and use this.

In that Black Horse Model has no control over the final assembly or material used for final assembly, Black Horse Model is not responsible for loss of use , or other incidental or consequential damages.

Furthermore, Black Horse Model cannot be held liable for personal injury or property damage caused by the use or misuse of Black Horse Model products. By the act of using the user-assembled products, the user accepts all resulting liability.

SAFETY PRECAUTION

- This is not a toy and pilots must be over the age of 14
- Be sure that no other flyers are using your radio frequency.
- Do not smoke near fuel
- Store fuel in a cool, dry place, away from children and pets.
- Wear safety glasses.
- The glow plug clip must be securely attached to the glow plug.
- Do not flip the propeller with your fingers.
- Keep loose clothing and wires away from the propeller.
- Do not start the engine if people are near. Do not stand in line with the side of the propeller.
- Make engine adjustments from behind the propeller only. Do not reach around the spinning propeller.
- Moisture causes damage to electronics. Avoid water exposure to all equipment not specifically designed and protected for this purpose.

IMPORTANT BUILDING NOTES

- Please trial fit all the parts. Make sure you have the correct parts and that they fit and are aligned properly before gluing! This will assure proper assembly. This kit is hand made from natural materials, every plane is unique and minor adjustments may have to be made. However, you should find the fit superior and assembly simple.

- The painted and plastic parts used in this kit are fuel proof. However, they are not tolerant of many harsh chemicals including the following: paint thinner, C/A glue accelerator, C/A glue debonder and acetone. Do not let these chemicals come in contact with the colors on the covering and the plastic parts.

- Some parts included in this kit such as the cowl or wheel pants are made of fiberglass, the fibers of which may cause eye, skin and respiratory tract irritation. Never blow into a part to remove fiberglass dust, as the dust will blow back into your eyes. Always wear safety goggles, a particle mask and rubber gloves when grinding, drilling and sanding fiberglass parts. Vacuum the parts and the work area thoroughly after working with fiberglass parts.

SUGGESTION

To avoid scratching your new airplane, do not unwrap the pieces until they are needed for assembly. Cover your workbench with an old towel or brown paper, both to protect the aircraft and to protect the table. Keep a couple of jars or bowls handy to hold the small parts after you open the bag.

FLIGHT WARNINGS

- Always operate in open areas, away from factories, hospitals, schools, buildings and houses etc.
- NEVER fly your aircraft close to people or built up areas.
- NEVER fly near power lines, aerials or other dangerous areas including airports, motorways etc.
- NEVER fly in wet conditions or on windy or stormy days.
- ALWAYS adjust the engine from behind the propeller, and do not allow any part of your body to be in line with the propeller.
- THE PROPELLER IS DANGEROUS Keep fingers, clothing (ties, shirt sleeves, scarves) or any other loose objects that could be caught or drawn in, away from the propeller. Take care at ALL times.
- NEVER use damaged or deformed propellers or spinners.
- Keep all onlookers (especially small children and animals) well back from the area of operation. This is a flying aircraft, which will cause serious injury in case of impact with a person or animal.
- DO NOT dispose of empty fuel containers on a fire, this can lead to an explosion.

www.modellmarkt24.ch

FLIGHT WARNINGS

- When ready to fly, first extend the transmitter aerial.
- Switch on the transmitter.
- Switch on the receiver.
- Check that the wings are correctly fitted to the fuselage.
- Operate the control sticks on the transmitter and check that the control surfaces move freely and in the CORRECT directions.
- Check that the transmitter batteries have adequate power.
- ALWAYS take off into the wind.
- If the model does not respond correctly to the controls, land it as soon as possible and correct the fault.
- ALWAYS land the model INTO the wind, this ensures that the model lands at the slowest possible speed.
- Switch off the receiver.
- Switch off the transmitter.
- Empty the fuel tank after flying, fuel left in the tank can cause corrosion and lead to engine problems.

COVERING TOOLS

- Top Flite® MonoKote® Sealing Iron
- Top Flite Hot Sock Iron Cover
- Top Flite MonoKote Trim Seal Iron
- Top Flite MonoKote Heat Gun

ADHESIVES AND REQUIRED TOOLS

- Thin CA
- 30-minute epoxy
- 6-minute epoxy
- Threadlocker thread locking cement
- Mixing sticks
- Mixing cups (GPMR8056)
- Epoxy brushes
- Denatured alcohol
- Canopy Glue
- Felt-tipped pen or pencil
- Flat screwdriver
- Adjustable wrench
- Drill
- Hobby knife
- Masking tape
- Phillips screwdriver (large)
- Phillips screwdriver (small)
- Ruler
- Sandpaper
- Solder
- Hex wrench
- Drill bit: 1/16-inch (1.5mm), 5/64-inch (2mm), 1/8-inch (3,2mm), 3/16-inch (4,8mm),11/64-inch (4.5mm), 13/64-inch (5,2mm), 1/4-inch (6,4mm)

Academy of Model Aeronautics National Model Aircraft Safety Code

Effective January 1, 2018

A. GENERAL: A model aircraft is a non-human-carrying device capable of sustained flight within visual line of sight of the pilot or spotter(s). It may not exceed limitations of this code and is intended exclusively for sport, recreation, education and/or competition. All model flights must be conducted in accordance with this safety code and related AMA guidelines, any additional rules specific to the flying site, as well as all applicable laws and regulations.

As an AMA member I agree:

• I will not fly a model aircraft in a careless or reckless manner.

• I will not interfere with and will yield the right of way to all human-carrying aircraft using AMA's See and Avoid Guidance and a spotter when appropriate.

• I will not operate any model aircraft while I am under the influence of alcohol or any drug that could adversely affect my ability to safely control the model.

• I will avoid flying directly over unprotected people, moving vehicles, and occupied structures.

• I will fly Free Flight (FF) and Control Line (CL) models in compliance with AMA's safety programming.

• I will maintain visual contact of an RC model aircraft without enhancement other than corrective lenses prescribed to me. When using an advanced flight system, such as an autopilot, or flying First-Person View (FPV), I will comply with AMA's Advanced Flight System programming.

• I will only fly models weighing more than 55 pounds, including fuel, if certified through AMA's Large Model Airplane Program.

• I will only fly a turbine-powered model aircraft in compliance with AMA's Gas Turbine Program.

• I will not fly a powered model outdoors closer than 25 feet to any individual, except for myself or my helper(s) located at the flightline, unless I am taking off and landing, or as otherwise provided in AMA's Competition Regulation.

• I will use an established safety line to separate all model aircraft operations from spectators and bystanders.

www.modellmarkt24.ch

- Officially designated AMA Air Show Teams (AST) are authorized to use devices and practices as defined within the Team AMA Program Document. (AMA Document #718.)

(j) Not operate a turbine-powered aircraft, unless in compliance with the AMA turbine regulations. (AMA Document #510-A.)

3. Model aircraft will not be flown in AMA sanctioned events, air shows or model demonstrations unless:

(a) The aircraft, control system and pilot skills have successfully demonstrated all maneuvers intended or anticipated prior to the specific event.

(b) An inexperienced pilot is assisted by an experienced pilot.

4. When and where required by rule, helmets must be properly worn and fastened. They must be OSHA, DOT, ANSI, SNELL or NOCSAE approved or comply with comparable standards.

B. RADIO CONTROL (RC)

1. All pilots shall avoid flying directly over unprotected people, vessels, vehicles or structures and shall avoid endangerment of life and property of others.
2. A successful radio equipment ground-range check in accordance with manufacturer's recommendations will be completed before the first flight of a new or repaired model aircraft.
3. At all flying sites a safety line(s) must be established in front of which all flying takes place. (AMA Document #706.)

(a) Only personnel associated with flying the model aircraft are allowed at or in front of the safety line.

(b) At air shows or demonstrations, a straight safety line must be established.

(c) An area away from the safety line must be maintained for spectators.

(d) Intentional flying behind the safety line is prohibited.

4. RC model aircraft must use the radio-control frequencies currently allowed by the Federal Communications Commission (FCC). Only individuals properly licensed by the FCC are authorized to operate equipment on Amateur Band frequencies.
5. RC model aircraft will not knowingly operate within three (3) miles of any pre-existing flying site without a frequency-management agreement. (AMA Documents #922 and #923.)
6. With the exception of events flown under official AMA Competition Regulations, excluding takeoff and landing, no powered model may be flown outdoors closer than 25 feet to any individual, except for the pilot and the pilot's helper(s) located at the flightline.
7. Under no circumstances may a pilot or other person touch an outdoor model aircraft in flight while it is still under power, except to divert it from striking an individual.
8. RC night flying requires a lighting system providing the pilot with a clear view of the model's attitude and orientation at all times. Hand-held illumination systems are inadequate for night flying operations.
9. The pilot of an RC model aircraft shall:

(a) Maintain control during the entire flight, maintaining visual contact without enhancement other than by corrective lenses prescribed for the pilot.

(b) Fly using the assistance of a camera or First-Person View (FPV) only in accordance with the procedures outlined in AMA Document #550.

(c) Fly using the assistance of autopilot or stabilization system only in accordance with the procedures outlined in AMA Document #560.

C. FREE FLIGHT


1. Must be at least 100 feet downwind of spectators and automobile parking when the model aircraft is launched.
2. Launch area must be clear of all individuals except mechanics, officials, and other fliers.
3. An effective device will be used to extinguish any fuse on the model aircraft after the fuse has completed its function.

D. CONTROL LINE

1. The complete control system (including the safety thong where applicable) must have an inspection and pull test prior to flying.
2. The pull test will be in accordance with the current Competition Regulations for the applicable model aircraft category.
3. Model aircraft not fitting a specific category shall use those pull-test requirements as indicated for Control Line Precision Aerobatics.
4. The flying area must be clear of all utility wires or poles and a model aircraft will not be flown closer than 50 feet to any above-ground electric utility lines.
5. The flying area must be clear of all nonessential participants and spectators before the engine is started.

www.modellmarkt24.ch


Servo extension leads.




620mm..... 10pcs.

190mm..... 2pcs.


420mm..... 6pcs.



Turbine Jet Engine with thrust 14kg



- Servo for Aileron 20-30 kg (x2) – Standard size 20 x 40mm
- Servo for Flap 30-40 kg (x2) – Standard size 20 x 40mm
- Servo for Elevator 20-30 kg (x2) – Standard size 20 x 40mm
- Servo for Rudder 20-30 kg (x1) – Standard size 20 x 40mm
- Servo for Gear door 20-30 kg (x3) – Standard size 20 x 40mm
- Servo for Nose steering 10-16 kg (1)- Medium size 18 x 36mm



LiPo: 3s.....1 Packs

LiPo: 2s.....3 Packs

2x900mm


Deg High Temperature Braided Soft Chemical Fiber Tubing

---2


TOOLS & SUPPLIES NEEDED.



Medium C/A glue



Straight edge ruler.



30 minute epoxy.
5 minute epoxy.



Hex Wrench.




Hand or electric drill.




Threadlocker (screw cement).



2 bender plier



Screw driver



Wire cutters.



Modeling knife.



Some more tools.

- Assorted drill bits.
- Masking tape.
- Paper towels.
- Rubbing alcohol
- 90° square or builder's triangle.

Symbols used throughout this instruction manual, comprise:



Cut off excess.



Apply threadlocker (screw cement).



Must be purchased separately!



Cut off shaded portion carefully.



Apply instant glue (C.A glue, super glue).



Ensure smooth, non-binding movement when assembling.



Pay close attention here.



Apply epoxy glue.



Drill holes using the stated (in this case 1.5mm ø).



Take particular care here.



Assemble left and right sides the same way



The number of times the same way Assembly (in this case twice).



Set all screws securely . If they come off during flight you will lose control of your aircraft!




Use a pencil to mark

www.modellmarkt24.ch

1: Fuselage set. 2-2a:Pilot - 2b: Cockpit set -2c: Canopy . 3: Wing set. 4: Horizontal stabilizer set 5: Vertical stabilizer set. 6-6a: Nose gear & door gear set. 7-7a: Main gear & door gear set. 8: Stainless tailpipe 9: Fuel tank set. 10: Controller box set. 11: CG set. 12: Battery strap.

❶



- - - 1

4 x 16 mm Button Head Cap Screw - - - - - - - - 4

4mm Aluminum Washer - - - - - - - - - 4


❷

Pilot **2a**




- - - 1

Canopy **2c**




- - - 1

Cockpit set **2b**



- - - 1

❸



- - - 1

6x50mm Aluminum - - - 4

Ø12x860mm Fiber Carbon Tube - - - 1

Ø20x1084mm Fiber Carbon Tube - - - 1

<for Ailerons>

3mm Flat Washer - - - - - - - - - - - 4

3mm Lock Nut - - - - - - - - - - - 2

3x12 Button Head Cap Screw - - - - - - - - - - - 2

3x16 Button Head Cap Screw - - - - - - - - - - - 2

Copper ball - - - - - - - - - - - 4

- - - - - - - - - 4

3x55mm Push Rod for Ailerons - - - - - - - 2

<for Flaps>

3mm Flat Washer - - - - - - - - - - - 4

3mm Lock Nut - - - - - - - - - - - 2

3x12 Button Head Cap Screw - - - - - - - - - - - 2


3x16 Button Head Cap Screw - - - - - - - - - - - 2

Copper ball - - - - - - - - - - - 4

- - - - - - - - - 4

3x60mm Push Rod for Flaps - - - - - - - 2

❹



- - - 1

3mm Flat Washer - - - - - - - - - - - 4

6x50mm Aluminum - - - - - - - - - - - 2

3x12 Button Head Cap Screw - - - - - - - - - - - 2

3mm Lock Nut - - - - - - - - - - - 2

3x16 Button Head Cap Screw - - - - - - - - - - - 2

Copper ball - - - - - - - - - - - 4

- - - - - - - - - 4

3x65mm Push Rod - - - - - - - 2

Ø12x570mm Fiber Carbon Tube - - - 1

Ø8x378mm Fiber Carbon Tube - - - 1

❺

2.6 x 10mm Button Head Cap Screw - - - - - - - - - - - - 8

3 x 12mm Button Head Cap Screw - - - - - - - - - - - - 1

3 x 16 Button Head Cap Screw - - - - - - - - - - - 1

3mm Flat Washer - - - - - - - - - - - 2

3mm Lock Nut - - - - - - - - - - - 1

Plastic - - - - - - - - - - - 2


Copper ball - - - - - - - - - - - 2

- - - - - - - - - 2

3 x 50mm Push Rod - - - - - - - 1

www.modellmarkt24.ch

Nose Gear



- 1

3x12 Button Head Cap Screw - 2

3mm Flat Washer - 2

Copper ball - 2

- 2

2.6 x 30 mmPush Rod - 1

3 x 4mm Set Screw - 1

4 x 20 Button Head Cap Screw - 4

4mm Spring Washer - 4

6

3 x 12mm Button Head Cap Screw - 2

3mm Flat Washer - 2

Aluminum Ball - 1


Copper ball - 1

- 2

2.6 x 30 mmPush Rod - 1

6a

Main landing gear



- 1

3 x 12mm Button Head Cap Screw - 4

3mm Flat Washer - 4

2.6 x 20 mm Push Rod - 2

3mm Lock Nut - 2

Copper ball - 4

- 4

4 x 20 Button Head Cap Screw - 8

3 x 4mm Set Screw - 2

4mm Spring Washer - 8

7

3 x 12mm Button Head Cap Screw - 4

3mm Flat Washer - 4

Aluminum Ball - 2


Copper ball - 2

- 4

2.6 x 15 mmPush Rod - 2

7a

Stainless tailpipe



- 1

3 x 15mm Button Head Cap Screw - 10

8

Clunks - 1

Rubber - 1

Ziptie - 4

3x25mm Screw - 1

Aluminum - 1

Aluminum - 1

87mm Copper tube - 1

55mm Copper tube - 2

Fiber glass - 1

Alu. Anodized Fuel Vent Line Plug - 1

2x5mm Tp Screw - 9

Magnetic Anodized Fuel Dot - 1


20 x 560mm Fuel tank velcro



- 2

9

Plate of plywood



- 2

Aluminum ∅12mm

100mm - 1

2000mm Wire



- 1

11

15 x 220mm Velcro battery


12



- 3

Controller Box

10



- 1

www.modellmarkt24.ch

INSTALLING THE AILERONS AND FLAPS SERVOS

<for Ailerons>

3mm Flat Washer ----------4

3mm Lock Nut ----------2

3x12 Button Head Cap Screw ----------2

3x16 Button Head Cap Screw ----------2

Copper ball ----------4

---------4

3x55mm Push Rod for Ailerons -------2

<for Flaps>

3mm Flat Washer ----------4

3mm Lock Nut ----------2


3x12 Button Head Cap Screw ---------- 2


3x16 Button Head Cap Screw ----------2


Copper ball ----------4


---------4

3x60mm Push Rod for Flaps -------2











L/R Assemble left and right sides the same way

Ensure smooth, non-binding movement when assembling.

Pay close attention here.

www.modellmarkt24.ch






Warning!

► Set all scerws securely. If they come off during flight you will lose control of your aircraft!

Ⓐ Tie the string.

Ⓑ Pull out servo cord with string.



Warning!

► Set all screws securely. If they come off during flight you will lose control of your aircraft!


L/R Assemble left and right sides the same way


X Must be purchased separately!

1.5mm Drill holes using the stated (in this case 1.5mm ø).

www.modellmarkt24.ch

INSTALLING THE LIGHT WING AND WINGS TIP






X Must be purchased separately!

L/R Assemble left and right sides the same way

A B Apply epoxy glue.

x2 The number of times the same way Assembly (in this case twice).

INSTALLING THE MAIN LANDING GEAR AND GEAR DOOR



3 x 12mm Button Head Cap Screw ---------- 4

3mm Flat Washer ---------- 4

3mm Lock Nut -------- 2

Copper ball -------- 4

---- 4

2.6 x 20 mmPush Rod


-------- 2


4 x 20 Button Head Cap Screw ---------- 8


4mm Spring Washer ---------- 8

3 x 4mm Set Screw ---------- 2

www.modellmarkt24.ch









Ensure smooth, non-binding movement when assembling.

Assemble left and right sides the same way


Pay close attention here.


www.modellmarkt24.ch





< Bottom view >





Assemble left and right sides the same way

www.modellmarkt24.ch

INSTALLING THE MAIN GEAR DOOR SERVOS

3 x 12mm Button Head Cap Screw ---------- 4

3mm Flat Washer ---------- 4


3mm Lock Nut -------- 2


Aluminum Ball -------- 2


Copper ball -------- 2

---- 4

2.6 x 15 mmPush Rod -------- 2








A B Apply epoxy glue.


Cut off shaded portion carefully.


L/R Assemble left and right sides the same way


Ensure smooth, non-binding movement when assembling.


www.modellmarkt24.ch















Pay close attention here. Ensure smooth, non-binding movement when assembling. Assemble left and right sides the same way. Must be purchased separately!

www.modellmarkt24.ch


ELECTRIC RETRACT SYSTEM



JOINING THE FUSELAGE

4 x 16 mm Button Head Cap Screw - - - - - - - - 4

4mm Aluminum Washer - - - - - - - - - 4




www.modellmarkt24.ch


SECURE THE WING TO THE FUSELAGE


Ø12x860mm Fiber Carbon Tube --- 1

Ø20x1084mm Fiber Carbon Tube --- 1

6x50mm Aluminum --- 4








X Must be purchased separately!

Apply threadlocker (screw cement).


L/R Assemble left and right sides the same way

www.modellmarkt24.ch




* Multiplex Connection 10 Pin (Item: 18901)
(Must Be Purchased Separately):


❶ < Aileron >




❷ < Flap >



❸ < Main Gear >



❹ < Brakes >



Assemble in the specified order.

X Must be purchased separately.

L/R Assemble left and right sides the same way

www.modellmarkt24.ch

INSTALLING THE VERTICAL AND STABILIZER PUSHROD

2.6 x 10mm Button Head Cap Screw ---------- 8

3 x 12mm Button Head Cap Screw ---------- 1

3 x 16 Button Head Cap Screw ---------- 1

3mm Flat Washer ---------- 2


3mm Lock Nut ---------- 1


Plastic ---------- 2

Copper ball ---------- 2

---------- 2

3 x 50mm Push Rod ------- 1





x4 The number of times the same way Assembly (in this case twice).

x2 The number of times the same way Assembly (in this case twice).

L/R Assemble left and right sides the same way

1.5mm Drill holes using the stated (in this case 1.5mm ø).

X Must be purchased separately!

www.modellmarkt24.ch

INSTALLING THE ELEVATOR SERVOS

3x12 Button Head Cap Screw ---------- 2

3x16 Button Head Cap Screw ---------- 2

3mm Flat Washer ---------- 4


3mm Lock Nut ---------- 2


Copper ball ---------- 4

---------- 4

3x65mm Push Rod

-------- 2






Pay close attention here.


X Must be purchased separately.


L/R Assemble left and right sides the same way.


www.modellmarkt24.ch


INSTALLING THE ELEVATOR PUSHROD











L/R Assemble left and right sides the same way


www.modellmarkt24.ch


INSTALLING THE HORIZONTAL STABILIZER TO FUSELAGE

Ø12x570mm Fiber Carbon Tube --- 1

Ø8x378mm Fiber Carbon Tube --- 1

6x50mm Aluminum ---------- 2





Apply threadlocker (screw cement).

Assemble left and right sides the same way

www.modellmarkt24.ch

INSTALLING THE NOSE GEAR RETRACT

3x12 Button Head Cap Screw ---------- 2

3mm Flat Washer ---------- 2

Copper ball -------- 2

---- 2


2.6 x 30 mmPush Rod -------- 1

3 x 4mm Set Screw -------- 1


4 x 20 Button Head Cap Screw ---------- 4

4mm Spring Washer ---------- 4


Controller Box





Nose Gear




-- 1










X Must be purchased separately!

L/R Assemble left and right sides the same way

www.modellmarkt24.ch



x4 The number of times the same way Assembly (in this case twice).

NOSE DOOR INSTALLING

3 x 12mm Button Head Cap Screw ---------- 2


3mm Flat Washer ---------- 2

Aluminum Ball -------- 1

Copper ball -------- 1


---- 2


2.6 x 30 mmPush Rod -------- 1



x2 The number of times the same way Assembly (in this case twice).


www.modellmarkt24.ch






Must be purchased separately!

www.modellmarkt24.ch



x4 The number of times the same way Assembly (in this case twice).

INSTALLING THE STAINLESS TAILPIPE




www.modellmarkt24.ch

INSTALLING THE FUEL TANK


Clunks --- 1
Rubber --- 1
3x25mm Screw --- 1
Aluminum --- 1
Aluminum --- 1
87mm Copper tube --- 1
55mm Copper tube --- 2
Ziptie --- 4
Fiber glass --- 1
20 x 560mm Fuel tank velcro --- 2


INSTALLING THE STOPPER



X Must be purchased separately!


www.modellmarkt24.ch






X Must be purchased separately!


FUEL SYSTEM



www.modellmarkt24.ch


INSTALLING THE SMOKE PUMP





X Must be purchased separately!

SMOKE SYSTEM



www.modellmarkt24.ch

Magnetic Anodized Fuel Dot



- - - - - 1

Alu. Anodized Fuel Vent Line Plug




- - - - - 1


2x5mm TP Screw




- - - - - 9



< Top View >




< Top View >




x2 The number of times the same way Assembly (in this case twice).


INSTALLING THE ENGINE




X Must be purchased separately!

www.modellmarkt24.ch









X Must be purchased separately!


www.modellmarkt24.ch

INTALLING THE RECEIVER, B ATTERY, CONTROLLER BOX AND SWITCH




INSTALLING THE COCKPIT FUSELAGE





A B Apply epoxy glue.

www.modellmarkt24.ch



Pay close attention here.

BALANCING

1. It is critical that your airplane be balanced correctly. Improper balance will cause your plane to lose control and crash.

THE CENTER OF GRAVITY IS LOCATED 195mm (7.67in) BACK FROM THE LEADING EDGE OF THE WING, AT THE FUSELAGE. BALANCE A PLANE UPSIDE DOWN WITH THE FUEL TANK EMPTY.


2. If the nose of the plane falls, the plane is nose heavy. To correct this first move the battery pack further back in the fuselage. If this is not possible or does not correct it, stick small amounts of lead weight on the fuselage under the horizontal stabilizer. If the tail of the plane falls, the plane is tail heavy. To correct this, move the battery and receiver forward or if this is not possible, stick weight into the firewall. When balanced correctly, the airplane should sit level or slightly nose down when you lift it up with your fingers.

LATERAL BALANCE

After you have balanced a plane on the C.G. You should laterally balance it. Doing this will help the airplane track straighter.

1. Turn the airplane upside down. Attach one loop of heavy string to the engine crankshaft and one to the tail wheel wire. With the wings level, carefully lift the airplane by the string. This may require two people to make it easier.

2. If one side of the wing fall, that side is heavier than the opposite. Add small amounts of lead weight to the bottom side of the lighter wing half's wing tip. Follow this procedure until the wing stays level when you lift the airplane.




www.modellmarkt24.ch


- ▶ In order to obtain the CG specified, reposition the receiver and other equipment.
- ▶ If not obtain the CG specified, add a weight and adjust.

Warning!

► Do not fly before confirming the correct location of the CG. If the CG is incorrect, you lose control of your airplane which leads to accidents.



L/R Assemble left and right sides the same way



Pay close attention here.

www.modellmarkt24.ch

CONTROL THROWS


1. We highly recommend setting up a plane using the control throws listed.
2. The control throws should be measured at the widest point of each control surface.
3. Check to be sure the control surfaces move in the correct directions.


- **LOW RATE**

Ailerons	: 12mm up	12mm down
Elevator	: 10mm up	10mm down
Rudder	: 35mm right	35mm left
Flap	: 25mm down for take off	


- **HIGH RATE**


Ailerons	: 15mm up	15mm down
Elevator	: 14mm up	14mm down
Rudder	: 50mm right	50mm left
Flap	: Landing: 40mm down	







Aileron Control







Elevator Control






Rudder Control





Flap Control

www.modellmarkt24.ch




FLIGHT PREPARATION PRE FLIGHT CHECK

1. Completely charge your transmitter and receiver batteries before your first day of flying.
2. Check every bolt and every glue joint in your plane to ensure that everything is tight and well bonded.
3. Double check the balance of the airplane
4. Check the control surface
5. Check the receiver antenna . It should be fully extended and not coiled up inside the fuselage.
6. Properly balance the propeller.

FOR YOUR RADIO INSTALLATION
BASIC CONNECTION FOR AIRPLANE AND ADJUSTMENT OF SERVOS


Example of connection

- For more information, refer to radio system instruction manual.
- Follow instruction manual of Engine and Battery.




www.modellmarkt24.ch

NOSE GEAR DIMENSIONAL DETAIL




MAIN GEAR DIMENSIONAL DETAIL




www.modellmarkt24.ch


I/C FLIGHT GUIDELINES




When ready to fly, first extend the transmitter aerial.




Operate the control sticks on the transmitter and check that the control surfaces move freely and in the CORRECT directions.




ALWAYS land the model INTO the wind, this ensures that the model lands at the slowest possible speed.




Switch on the transmitter.




Check that the transmitter batteries have adequate power.




Switch off the receiver.




Switch on the receiver.




ALWAYS take off into the wind.




Switch off the transmitter.



Check that the wings are correctly fitted to the fuselage.



If the model does not respond correctly to the controls, land it as soon as possible and correct the fault.



Empty the fuel tank after flying, fuel left in the tank can cause corrosion and lead to engine problems.

Made in Vietnam

www.modellmarkt24.ch