If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

OPTIONAL BATTERY AND CHARGERS

The battery included with the Dromida XL is a standard sized 2200mAh 7.4V LiPo. The FlightPower FP30 7.4V 2200mAh 30C would be an acceptable substitute.

FPWP3222 FlightPower LiPo FP30 2S 7.4V 2200mAh 30C Star Plug

There are many chargers on the market that are capable of charging the LiPo included with the Dromida XL as well as other battery sizes and chemistries. Here are a few chargers that we recommend as upgrades to the charger included with the Dromida XL:

DTXP4225 Duratrax Onyx 225 AC/DC Advanced Charger





DTXP4255 Duratrax Onyx 255 AC/DC Dual Balancing Charger

GPMM3155 Great Planes ElectriFly Triton EQ AC/DC Charger



REPLACEMENT PARTS


1	DIDE1240	Prop Guards and Mount Plates
2	DIDE1241	Prop Set **Blue/Black** XL370
2	DIDE1242	Prop Set **Green/Black** XL370
2	DIDE1243	Prop Set **Orange/Black** XL370
2	DIDE1244	Prop Set **Red/Black** XL370
3	DIDE1245	Canopy **Green** XL370
3	DIDE1246	Canopy **Blue** XL370
3	DIDE1247	Canopy **Orange** XL370
3	DIDE1248	Canopy **Red** XL370
4	DIDE1249	Canopy Air Damper XL370
5	DIDE1250	Bearing Set XL370
6	DIDE1300	Main Frame **Green** XL 370
6	DIDE1301	Main Frame **Blue** XL 370
6	DIDE1302	Main Frame **Orange** XL 370
6	DIDE1303	Main Frame **Red** XL 370
7	DIDE1255	Gear Set XL370
8	DIDE1256	Prop Shafts XL370
9	DIDE1257	Motor Cover XL370
10	DIDE1290	Frame Bottom **Orange** XL370 V2
10	DIDE1291	Frame Bottom **Blue** XL 370 V2
10	DIDE1292	Frame Bottom **Green** XL 370 V2
10	DIDE1293	Frame Bottom **Red** XL 370 V2
11	DIDE1294	E-board XL 370 V2 **Orange** LED
11	DIDE1295	E-board XL 370 V2 **Blue** LED
11	DIDE1296	E-board XL 370 V2 **Green** LED
11	DIDE1297	E-board XL 370 V2 **Red** LED
12	DIDE1263	E-board Dampers XL370
13	DIDE1264	Camera Mount Assembly XL370 FPV
14	DIDE1265	Landing Pads XL370
15	TACZ1020	1080P Camera XL370 FPV
15	TACZ1005	Camera Power Wire
16	DIDE1235	2S, 2200mAh LiPo Battery XL370
17	DIDE1266	Main Motor CW L/F, R/R XL370
18	DIDE1267	Main Motor CCW R/F, L/R XL370
19	DIDE1268	Screw Set XL370
20	DIDE1269	Camera Mount Dampers XL 370 FPV
	DIDJ1106	MR101 Transmitter
	DIDE1236	2S/3S Balance Charger
	DIDE1237	A/C Adapter, 2S/3S Charger
22	DIDE1298	LED Lens Cover XL 370 V2
	DIDE1215	TX Mobile Phone Holder
	TACZ1010	Tactic 4GB C10 Micro Memory Card

TO CONVERT XL UAV TO FPV

13	DIDE1264	Camera Mount Assembly XL370 FPV
15	TACZ1020	1080P Camera XL370 FPV
	TACZ1010	Tactic 4GB C10 Micro Memory Card

www.modellmarkt24.ch

EXPLODE VIEW



www.modellmarkt24.ch